



CONNECT DIRECTLY AN AMS CAMERA ON YOUR TERMINAL INCOMMAND 800 OR 1200

AGL INCOMMAND

You can connect up to 4 AMS cameras using only 1 dedicated cable AGL INCOMMAND on your machine.



YOUR ORIGINAL MONITOR
AG INCOMMAND 800 OR 1200*



AN AMS CAMERA X4*

PRODUCTS NEEDED



Dedicated cable
VICAM-AMS-AGL-INCOMMAND



Camera
VICAM-AMS-CAM-PAL*

Extension cable from 2 to 20 m
VICAM-AMS-CR2 À 20



Your original monitor
INCOMMAND 1200*



Your original monitor
INCOMMAND 800*

*CAUTION :

Camera and original monitor are not included.
All the AMS cameras are compatible with this dedicated cable.